



如何更改SANNAV内部SFTP密码

https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/How_to_change_the_SANNAV_intern...

Updated: Wed, 22 Apr 2026 07:30:16 GMT

适用场景

SANNAV 2.2.x

问题描述

需要更改内部SFTP/SCP服务器的密码