



---

## 如何通过SANNNAV为性能设置端口警报

[https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/How\\_To\\_Setup\\_Port\\_Alerts\\_for\\_Perfo...](https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/How_To_Setup_Port_Alerts_for_Perfo...)

Updated: Wed, 22 Apr 2026 07:33:24 GMT

### 适用场景

SANnav  
Brocade

### 问题描述

- 如何设置端口级别的吞吐量性能监控。