



---

## Brocade G630 交换机端口的 LED 不起作用

[https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/LED\\_not\\_working\\_for\\_Brocade\\_G630...](https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/LED_not_working_for_Brocade_G630...)

Updated: Wed, 22 Apr 2026 08:47:58 GMT

### 适用场景

Brocade (G630)

### 问题描述

Brocade 前端 SAN 交换机的 LED 指示灯信号不起作用。