



无法在Brocade交换机上禁用TLS1.0和1.1

https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Unable_to_disable_TLS1.0_and_1.1_...

Updated: Wed, 22 Apr 2026 09:01:35 GMT

适用场景

- Brocade G620交换机
- FOS 9.1.x

问题描述

无法使用root权限禁用TLS1.0和1.1