



哪些平台支持NetApp卷加密(NVE)？

https://kb-cn-stage.netapp.com/on-prem/ontap/dm/Encryption/Encryption-KBs/Which_platforms_support...

Updated: Wed, 22 Apr 2026 07:28:44 GMT

不
可不使用

适用场景

- ONTAP 9

问题解答

要使用NetApp卷加密、该平台必须支持AES-NI指令集并运行ONTAP 9.1及更高版本。
应支持与ONTAP 9及更高版本捆绑的所有下一代控制器。

使用Hardware Universe验证 您的平台是否支持NVE。

步骤：

1. 打开 [Hardware Universe](#)

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

2. 选择"平台"下拉列表
3. 根据您的系统选择"Fabric连接存储(FAS)"或"All-Flash FAS (AFF)"
4. 选择"使用平台启动"按钮
5. 选择您的平台、ONTAP版本、然后在规范筛选器中键入"Encryption (加密)"并选择所有
- 6项。单击"显示结果"

7. 向下滚动以查看是否支持NVE

追加信息

- [Hardware Universe](#)