



---

## 如何更改ONTAP SAN控制器管理IP地址

[https://kb-cn-stage.netapp.com/on-prem/ontap/da/SAN/SAN-KBs/How\\_to\\_change\\_ONTAP\\_SAN\\_contr...](https://kb-cn-stage.netapp.com/on-prem/ontap/da/SAN/SAN-KBs/How_to_change_ONTAP_SAN_contr...)

Updated: Wed, 22 Apr 2026 07:31:11 GMT

### 适用场景

ONTAP SAN

### 问题描述

如何更新SAN阵列的管理接口？