



## ONTAP S3 容量层在启用了 FabricPool 的聚合中不可用

[https://kb-cn-stage.netapp.com/on-prem/ontap/da/S3/S3-KBs/ONTAP\\_S3\\_capacity\\_tier\\_unavailable\\_in...](https://kb-cn-stage.netapp.com/on-prem/ontap/da/S3/S3-KBs/ONTAP_S3_capacity_tier_unavailable_in...)

Updated: Wed, 22 Apr 2026 07:28:50 GMT

### 适用场景

- ONTAP 9
- ONTAP S3
- FabricPool

### 问题描述

FabricPool 聚合无法连接到 ONTAP S3 对象存储。

```
::> aggr show
```

Aggregate	Size	Available	Used%	State	#Vols	Nodes	RAID Status
aggr_1	65.80TB	45.68TB	31%	online	3	node01	raid_dp, tier_

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
aggr2_1 65.80TB 9.06TB 86% unavailable,  
normal  
online 6 node02 raid_dp,  
tier_  
unavailable,  
normal
```