CPU0_Error传感器处于断言状态

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/CPU0_Error_sensor_is_in_Asserted_s…
Updated: Wed, 22 Apr 2026 07:28:54 GMT

适用场景

- FAS8200
- AFF A300

问题描述

- 控制器故障LED亮起、故障显示在中 `SP-LATEST-IPMI`

> tag origin fld fault reason count ---- ------- ---- ---------- ------ 1 0x5 /chassis-1/controller-a Temperature Sensor 6 Fault 1

- `PCH_Hot` 在中处于已断言状态 `SP-LATEST-IPMI`

> Sensor Name | Current | Unit | Status | LCR | LNC | UNC | UCR ---------- ---------- ---------- ---------- ---------- ---------- ---------- CPU0_Error | 0x0 | discrete | Asserted | na | na | na | na

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information