



SAS扩展器已打开机箱LED

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/SAS_Expander_has_set_the_Chassis...

Updated: Wed, 22 Apr 2026 11:39:20 GMT

适用场景

- AFF A200
- FAS 2750

问题描述

- 两个节点上的系统故障LED均呈琥珀色。

示例：

```
200::*> system controller service-event show
```

Node	ID	Event Location	Event Description
A200-01	1	Chassis 1	SAS Expander has set the Chassis LED ON

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
A200-02      1  Chassis 1          SAS Expander has set the Chassis LED
ON
```

- 模块A/B扩展器温度显示故障。

示例：

```
A200::*> system node environment sensors show
```

```
Node Sensor          State Value/Units Crit-Low Warn-Low Warn-Hi Crit-Hi
-----
```

```
A200-01
```

```
  CPU0 Temp Margin
```

```
    init-failed
```

```
      - C      -      -      0      -1
```

```
  CPU0 Core Temp    normal
```

```
    38 C      0      5      90      100
```

```
  PCM_Inlet_Temp    normal
```

```
    28 C      0      5      67      72
```

```
A200-02
```

```
  PSU2 FRU          normal
```

```
    GOOD
```

```
  PSU1 FRU          normal
```

```
    GOOD
```

```
  SP Status         normal
```

```
    IPMI_HB_OK
```

```
  Partner Status
```

```
    not-available
```

```
  PSU1 Present
```

```
    not-available
```

```
  PSU1 5V
```

```
    not-available
```

```
      - mV      -      -      -      -
```

```
  PSU1 12V
```

```
    not-available
```

```
      - mV      -      -      -      -
```

```
  PSU1 5V Curr
```

```
    not-available
```

```
      - mA      -      -      -      -
```

```
  PSU1 12V Curr
```

```
    not-available
```

	- mA	-	-	-	-
PSU1 Fan 1	not-available				
	- RPM	-	-	-	-
PSU1 Fan 2	not-available				
	- RPM	-	-	-	-
PSU1 Inlet Temp	not-available				
	- C	0	5	57	62
PSU1 Hotspot Temp	not-available				
	- C	0	5	90	100
PSU2 Present	not-available				
PSU2 5V	not-available				
	- mV	-	-	-	-
PSU2 12V	not-available				
	- mV	-	-	-	-
PSU2 5V Curr	not-available				
	- mA	-	-	-	-
PSU2 12V Curr	not-available				
	- mA	-	-	-	-
PSU2 Fan 1	not-available				
	- RPM	-	-	-	-
PSU2 Fan 2	not-available				
	- RPM	-	-	-	-
PSU2 Inlet Temp	not-available				
	- C	0	5	57	62
PSU2 Hotspot Temp	not-available				
	- C	0	5	90	100
PSU_FAN					

```

not-available
Module B Expander Temp
    failed
    - C      0      5      80      90
Module A Expander Temp
    failed
    - C      0      5      80      90
Midplane 4 Temp      failed
    - C      0      5      55      60
Midplane 3 Temp      failed
    - C      0      5      55      60
Midplane 2 Temp      failed
    - C      0      5      55      60
Midplane 1 Temp      failed
    - C      0      5      55      60
Ambient Temp         failed
    - C      0      5      47      52

```