



升级 ONTAP 后，ACP 模块仍处于重新启动状态

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/ACP_module_remained_in_rebooting_...

Updated: Fri, 24 Apr 2026 10:30:06 GMT

适用场景

FAS8200

问题描述

升级 ONTAP 后，ACP 模块仍处于重新启动状态。

```
NODE::*> storage shelf acp module show
```

Node	Module Name	State
------	-------------	-------

NODE1	2.13.A	rebooting
-------	--------	-----------

	2.10.A	rebooting
--	--------	-----------

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

	2.12.A	active
	2.13.B	rebooting
	1.3.A	rebooting
	1.3.B	rebooting
	2.11.A	rebooting
	2.11.B	rebooting
	2.12.B	rebooting
	2.10.B	rebooting
	1.4.B	rebooting
	1.1.B	rebooting
	1.0.A	rebooting
	1.1.A	rebooting
	1.0.B	rebooting
	1.4.A	rebooting
	1.2.B	rebooting
	1.2.A	rebooting
NODE2	2.13.A	rebooting
	2.10.A	rebooting
	2.12.A	active
	2.13.B	rebooting
	1.3.A	rebooting
	1.3.B	rebooting
	2.11.A	rebooting
	2.11.B	rebooting

2.12.B	rebooting
2.10.B	rebooting
1.4.B	rebooting
1.1.B	rebooting
1.0.A	rebooting
1.1.A	rebooting
1.0.B	rebooting
1.4.A	rebooting
1.2.B	rebooting
1.2.A	rebooting